

In this process pre chemically treated card like small sheets are slit into slim strips of liquid testing tabs often used in hematology. Following conversion the strips are decanted into their final packaging containers usually tubes.

To squeeze the spread of strips into a narrow necked vessel the strips are delivered down a funneling device. It is in the funnels where the charged lightweight strips often stick to the walls of the funnel due to electrostatic attraction.

By neutralizing the strips as they drop of the delivery line in to the funnel using a 1250S or 1260 single point AC bar, the test tabs drop easily into the container.

